


## DroneView Series: DV Connector



- Connects DV Commander or DV Patrol to internet for remote drone video viewing
- Internal LTE modem and antenna
- Pre-programmed for routing DroneView video images
- External connection to DV Commander or DV Patrol ('LAN')
- Powered off AC or internal battery
- Illuminated power switch
- Integrated battery charger
- Charging status indicator
- Modem status indicator

# DroneView Applications:

## Incident Management w/Backhaul



## Drone Patrol (Remote View)

